

DOSE IT PUMP MANUFACTURER INSTRUCTIONS

IMPORTANT

- Bio-Zyme Industrial is the **ONLY PRODUCT** tested and approved to use through the Bio-Zyme Dose It Pump, therefore, Bio-Zyme is the **only product to be used** within this pump.
- Ensure the Compliance Record is set up and filled in on **EVERY** replacement of Bio-Zyme Industrial. Records must be sent every 4 months to the Distributor.

Any questions? Please contact us or your Distributor for advice.

INSTALLATION

Bio-Zyme Dose It Pump must be installed under bench near a 3 point plug and away from water.

Tools:

- Bracket (supplied)
- Screws (supplied)
- Screwdriver

Instructions:

1. Ensure bracket (clear plastic block) is screwed to wall.
2. Remove front cover of pump and programme date & time. Replace front cover.
3. Slide pump down onto bracket.
4. Attach tubing to left side of head.
5. Remove lid from Bio-Zyme 5L Industrial bottle. Drill a hole into the lid to push plastic tubing through.
6. Replace lid on bottle (tip: use this same lid on every bottle when changing product).
7. Attach black pipe clear to tube coming through lid with fasten cable ties.
8. Attach the elbow into Grease convertor. Attach tube to right side of head and to pump. Secure tubing with cable ties.
9. Push up the black button at the bottom of the Dose It Pump to prime unit and ensure product is moving through squeeze tube to convertor.

DOSE IT PUMP WARRANTY

Essential Terms

The End user must be informed about:

- The P e-treatment Compliance Record;
- The 4 monthly record and the importance to send this back to the distributor;
- The Manufacturer's Instructions

Warranty Against Defects

1. Bio-Zyme warrants the Dose It Pump for all parts defective in workmanship or materials for a period of 2 years from the date of purchase (**Warranty Period**).

If the Dose It Pump proves defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Pump without charge.

Warranty Conditions

2. The Dose It Pump must be used in accordance with the Manufacturer's Instructions. This Warranty does not apply should the defect in or failure of the Dose It Pump be attributable to misuse, abuse, accident or non-observance of Manufacturer's Instructions on the part of the user.

3. In order to claim under the warranty granted under clause 1 you must:
 - a. Retain this warranty with your receipt/proof of purchase; and
 - b. Return the Dose It Pump to the Distributor within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name and its serial number and (ii) this Order Form.
4. This warranty is immediately void if:
 - a. Any serial number or appliance plate is removed or defaced;
 - b. The Dose It Pump has been serviced or otherwise repaired by a person not authorised to do so by Bio-Zyme or the distributor
 - c. Non approved replacement parts are used; or other product not the Bio-Zyme Industrial was used within the Dose It Pump.

Any questions? Please contact us or your Distributor for advice.